



Alerta Tinteiro



Toner HP	
HP 92274A	0
HP 92275A	0
HP 92291A/X	0
HP 92298A	0
HP 92298X	0
HP C3900A	0
HP C3903A	0
HP C3906A	0
HP C3909A	8
HP C3909X	8
HP C4092A	1
HP C4096A	1
HP C4127A	0
HP C4127X	2
HP C4129X	4
HP C4182X	4
HP C7115A	1
HP C7115X	1
HP C8061A	0
HP C8061X	1
HP C8543X	8
HP Q1338A	2
HP Q1339A	2
HP Q2610A	0
HP Q2612A	4
HP Q2613A	1
HP Q2613X	1
HP Q2624A	0
HP Q2670A	0
HP Q2671A	0
HP Q2672A	0
HP Q2673A	0
HP Q3694A	0
HP Q3960A	0
HP Q3961A	0
HP Q3962A	0
HP Q3963A	0
HP Q3970A	0
HP Q3971A	0
HP Q3972A	0
HP Q3973A	0
HP Q5942A	1
HP Q5942X	2
HP Q5945A	1

HP Q5945X	1
HP Q5949A	1
HP Q5949X	2
HP Q6000A	4
HP Q6001A	4
HP Q6002A	4
HP Q6003A	4
HP Q6470A	1
HP Q6471A	1
HP Q6472A	1
HP Q6473A	1
HP Q6511A	1
HP Q6511X	3
HP Q7516A	1
HP Q7553A	2
HP Q7553X	2
HP CB436A	0
HP C9730A	0
HP C9732A	0
HP C9733A	0
HP CB435	20
HP CB436	20
HP CB540	6
HP C541/2/3	6
HP CC530	4
HP CC531/2/3	4
HP CE505A	4
HP CE505X	6
HP CC364A	40
HP CC364X	40
Toner Canon	
Canon CRGH Cartridge	0
Canon EP-22	0
Canon EP-25	0
Canon EP-27	0
Canon FX-1	0
Canon FX-10	2
Canon FX-2	0
Canon FX-3	2
Canon FX-4	0
Canon FX-6	1
Canon FX-7	0
Canon FX-8	0
Canon M Cartridge	0
Canon T Cartridge	0
Canon 107/307/707	0
Toner Lexmark	

Lexmark 08A0476 Optra E330/332/232, Dell 1700, IBM 1412	3
Lexmark 08A0477 Optra E 320/322 Virgin	3
Lexmark 10S0150 Optra E210	3
Lexmark 12A0825, Optra Se	3
Lexmark 12A2202	3
Lexmark 12A5740/45 Optra T	3
Lexmark 12A5840/45	4
Lexmark 12A6730	4
Lexmark 12A6830/35 Optra T 520/522	4
Lexmark 12A6865/60 Optra T620/622 (excludes new model)	3
Lexmark 12A7305, Optra e321/323	3
Lexmark 12A7400	3
Lexmark 12A7405	3
Lexmark 12A7410/15A Optra T420	3
Lexmark 12A7460	3
Lexmark 12A7462 Optra T630/632	6
Lexmark 12A7465/9 Optra T630/632	6
Lexmark 12A8044	5
Lexmark 12A8400	3
Lexmark 12A8405	3
Lexmark 12A8420/25	5
Lexmark 12S0400	3
Lexmark 1380520, IBM 4019	3
Lexmark 1380850, IBM 4039	3
Lexmark 1380950, IBM 4039	3
Lexmark 1382100, IBM 4049 Low Yield	3
Lexmark 1382150, IBM 4049 High Yield	3
Lexmark 1382920/25, Optra S New Model	3
Lexmark 13T0101 Optra E 310/312	3
Lexmark 13T0301	3
Lexmark 140109/140127-X/140196 -A/140198 -X	2
Lexmark 15G042C/K 15W0902	3
Lexmark 17G0152/54	3
Lexmark 17G0154 Optra M410/412	3
Lexmark 18S0090	3
Lexmark 20K0503/4/20K1400/1/2/3	3
Lexmark 20S0014 Optra E220	3
Lexmark 24016SE/34016HE	3
Lexmark 4K00199	3
Lexmark 64016SE/64416XE/64440XE	3
Lexmark 6500S2KG	3
Lexmark 69G8256 Optra E	3
Lexmark 69G8257	3
Lexmark C500H2KG/C500S2CG/C500S2MG	3
Lexmark C5220CS/KS/MS/YS	3
Lexmark C7700CH/CS/KH/KS/MH/MS/XS/YH	3
Lexmark E120	3
Lexmark E210	3
Lexmark E350	3

Lexmark E352H11E/E450H11E	5
Lexmark X215	5
Lexmark X340A11G	5
Lexmark X340A11G	5
Toner Samsung	
Samsung ML1210	2
Samsung ML1520	2
Samsung ML1610	3
Samsung ML1710	1
Samsung ML2150	2
Samsung ML2250	3
Samsung ML2550	3
Samsung ML4100	4
Samsung ML4216	2
Samsung ML4521	4
Samsung SCX 4216 D3/SEE	1
Samsung ML2010	1
Samsung ML5100	1
Toner Brother	
Brother TN 2000	6
Brother TN 3030/3060	0
Brother TN 3130	1
Brother TN 3170	1
Brother TN 6300	0
Brother TN 6600	2
Brother TN 7600	2
Toner Dell	
Dell 1100-J9341/J9833	2
Dell 1600/1600N-P4210	2
Dell 1700/1700N-H3730/K3756	2
Dell 1815-RF234	2
Dell 3110CN/3115CN	2
Dell 5210 (GD531)	2
Toner Panasonic	
Panasonic UG-3309	2
Panasonic UG-3313	2
Panasonic UG-3350	4
Panasonic UG-5510 Virgin	4
Panasonic UG-5520 Virgin	2

WWW.ALERTATINTEIRO.COM
TELEFONE: 218473035